TRIUMPH BOARD TRIUMPH Share

(PC version)

USER GUIDE

- 1. Install the program "TRIUMPH Share.exe"
- 2. Follow the installation instruction

TRIUMPH Share - InstallShield Wizard		
4	Preparing to Install	
3	TRIUMPH Share Setup is preparing the InstallShield Wizard, which will guide you through the program setup process. Please wait.	
	Extracting: TRIUMPH Share.msi	
	Cancel	

3. Once the program is installed, the following icon will displayed on desktop



4. Run the program "TRIUMPH Share" clicking on this icon. The following windows will be displayed.

Note: You must have set up a Call if you want to use TRIUMPH Share sw.

	TRIUMPH Share v11.0.0.25	×
0	TRIUMPH Share	TRIUMPH BOARD [®]
C	onnection ———	
	+ -	Edit
		-
		Log In

TRIUMPH BOARD®



5. Click on the symbol "+" to add the new site.

	? ×
Connection Profile	
Profile Title:	
IP: , ,	
Access Code:	
ОК	Cancel

 Fill all fields in this window. Input "Profile Title" (any name), IP address of your TRIUMPH BOARD Video Conferencing System VC1 / VC4 (you can find it in Home menu – Network Settings – LAN Configuration – Your IP Address is) and predefined Access Code (you can find it in Home menu – General Settings – Administrator; there is "1234" as default). Also make sure that you have enabled the "Enable TRIUMPH Link / TRIUMPH Share" option in Home menu - General Settings - Administrator of your TRIUMPH BOARD Video Conferencing System VC1 / VC4. Finally, click OK.

	? 🗙
Connectio	on Profile
Profile	Title: TRIUMPH BOARD
IP:	10 20 30 40
Access	Code: ••••
	OK Cancel

7. Select the requested profile and click "Log In" at the bottom right.





8. The following window will appear



9. Press the option "Desktop" to share the desktop.

