


MAC touch driver for MULTI Touch LED LCD Android series

There're 2 types of touch drivers for MAC, it depends on touch frame firmware version of your LCD.

- 1) Please, on LCD remote control press the following keys combination INPUT3939, to get SW Information of your LED LCD



- 2) Find Touch info and the following 4 numbers (marked in red) i.e. **4333**



3) Select the appropriate MAC driver:

 Touch firmware ver. 4423&earlier

 Touch firmware ver. 4424&later

4) Unzip the file

 UPDD_V1476_No Area

5) Install the driver to your MAC computer

 UPDD_05_01_1476_NoArea.dmg