
LiftBox® for 65" / 70" LED LCD


Installation manual

LiftBox® for 65" / 70" LED LCD



MOUNT APPLICATION COVER


USE LIFTBOX VESA BRACKET ACCESSORIE




SET BALANCE, USE DRILL DRIVER LEFT/RIGHT 5 SEC COUNTER CLOCKWISE UNTIL BALANCED








LiftBox® for 65" / 70" LED LCD




Safety warnings, contents of the box, tools needed




MOUNT WALL BRACKET LEVEL TO THE WALL

REMOVE COVER FROM LIFTBOX



MAKE SURE SCREWS ARE UNLOCKED LIFT LIFTBOX ONTO THE BRACKET



LOCK LIFTBOX WITH LOCK SCEWS

LEVEL VERTICALLY WITH FEET AT THE BOTTOM