
LiftBox® for IWB's **Installation manual**


LiftBox® for IWB's




SET BALANCE, USE DRILL DRIVER LEFT/RIGHT 5 SEC COUNTER CLOCKWISE UNTIL BALANCED




LiftBox® for IWB's




Safety warnings, contents of the box, tools needed




MOUNT WALL BRACKET LEVEL TO MAKE SURE SCREWS ARE UNLOCKED THE WALL



LIFT LIFTBOX ONTO THE BRACKET LOCK LIFTBOX WITH LOCK SCEWS



LEVEL VERTICALLY WITH FEET AT THE BOTTOM



USE LIFTBOX ACCESSORIES

